




LHD




RHD







WITH SONY ® SOUND



WITH SONY® SOUND




SYNC GEN 1




SYNC GEN 1

ACCESSORY
PROTOCOL
INTERFACE
MODULE (APIM)
151-15


AUDIO CONTROL
MODULE (ACM)
151-16




MICROPHONE




AUDIO INPUT JACK 151-19




SYNC GEN 2




SYNC GEN 2




SYNC GEN 2




SYNC GEN 2






BASE AUDIO
RH UPPER SWITCH



PREMIUM AUDIO
RH UPPER SWITCH



WITH SONY® SOUND
RH UPPER SWITCH

